Switch Usage mode:

1) Switch to **Public Model**: press C and Enter (→), **then press 4**, then press the Enter key(→), and then enter the management password (the initial password is 00000000.),And then press Enter Key (→) to the lock out .

2) 2) Switch to **Private Model** : press C and Enter (→), **then press 5**, then press the Enter key(→), and then enter the management password (the initial password is 00000000.),And then press Enter Key (→) to the lock out .

2.OPERATION

>Change password

Change management **Code**

Master code (Default is "00000000") is consist of 4-10 digits number, it can be long term preservation even the interruption of power supply, the master code can change by the manager. The method of changing master code: keep pressing the"#"button about 5 seconds(yellow LED flicker)→ enter the old master code → press the"#"button→ enter the new master code→ press"#"button,and the new master code set successfully.

Remark: After used the master code to turn on lock, the user code will return back to the default code"0". Please change the master code in time and keeping properly for emergency.

Private mode change use code

User code (Default is"1111")is consist of 4-10 digits number,it can be long term preservation even the interruption of power supply, and it can be changed by users. The method of changing user code: Continuous press"#"button 2 times(Yellow LED flicker)→ Input old user code→ Press"#"button to confirm→ Input new user code → Press"#"button to confirm(Green LED flicker for a long time,buzzer make 2 sound of "Di,Di"), change user code success.

Public mode change the user code

The public type don't need to change user code, the code which used to turn off(lock) door is the code can open it.The code can set as customer demand (Must consist of 4-10 digits number)

>Turn on lock

Input new code (if you didn't change, please input default code"1111"), press"#"button to open when the green LED flash, then pull panel you can open door."*" is the elimination button. When user code was lost, use master code or the code-hopping to open, user code will return to default code"1111"

▶Turn off lock

Private type Push the cabinet door to the close situation, then can turn off lock.

Public type When cabinet lock at the state of opening (Latch/bolt at the state of retract),push cabinet door to the state of closing, input the password which you set, and press "#" button to confirm, then can turn off lock (Input the password you set, it can turn on lock again).